





Installation Instructions

NOTE: When mounting Kool Kap to condensing unit the outdoor temperature must be ABOVE 50° F.

If the outdoor temperature is below 50° F, the surface of the condensing unit must first be warmed where the three hinges will be placed. A hairdryer works well to bring the metal temperature up so it is warm to the touch.




The adhesive backing on the hinges is very strong. Work carefully in positioning each hinge, since once placed you will not get a second chance to reposition the hinge.

Positioning and Attaching



1. Clean and dry the top surface of condensing unit using a cleaner designed to cut grease and oil. Pay special attention to cleaning the area where the hinges will be attached. This will insure permanent adhesion.
2. Position the Kool Kap squarely on condensing unit, making sure the top fan grill opening will be fully covered by the Kool Kap. Don't worry if the front of the Kool Kap hangs over the condenser slightly.
3. Position the three hinges so they align with the three slots in the Kool Kap. Be sure that the location of the hinges allows for complete contact with the condensing unit.
4. Beginning with the middle hinge, remove the backing from the tape and carefully reposition the hinge for permanent mounting. Once positioned press firmly on the hinge for best adhesion.
5. Repeat this process for the left and right hinge, making sure the Kool Kap does not move.

Attaching the Strap



1. Feed the end of the strap under and around the inner rung of the top fan grill. Loop the strap back through the inside of the buckle so the strap is attached to the grill.
2. Adjust the strap length by sliding the buckle up and down so the Kool Kap opens completely to an 85° angle.
3. Turn on the air conditioner and verify the proper operation of the Kool Kap.
4. If you find that your new Kool Kap does not lift up to the fully open position easily and quickly when the condenser fan motor turns on check the following:
 - a. Make sure nothing is restricting the movement of the Kool Kap.
 - b. Make sure the strap is lengthened to allow the Kool Kap to open to a full 85°.
 - c. If your condenser uses a louvered grill like the one shown in the pictures above use a pair of needle nose pliers to open the louvers to a more horizontal position which will direct the air flow upward.

DO NOT OPERATE your air conditioner or heat pump if ice, snow or any other object is on top of the Kool Kap. Unless the Kool Kap can open freely when your system operates, damage to your system may occur.

Limited Warranty

The product Kool Kap is warranted for five (5) years from the original date of purchase to be free of manufacturer's defects. Proof of purchase may be required to honor warranty. Kool Kap, LLC, its employees and representatives will not be liable in any form should loss of efficiency or damage to any heat exchanging product, equipment or system occur due to the product Kool Kap being installed or used in any incorrect manner or altered due to acts of God and nature. All inquiries regarding the product and its warranty should be addressed to:

KOOL KAP, LLC

259 Hamburg Turnpike • PO Box 10 • Riverdale • New Jersey • 07457

■ Phone 800-878-6614 ■ e-mail info@KoolKap.com ■ Web www.KoolKap.com